

# Dry Tech Insulated Water Resistant Fleece Ladies' Jacket

100% brushed polyester tricot lined 3-panel hood with drawstring and toggles

Reverse coil zipper at centre front with **D** rubber zipper pull

Igles **DF7680L** 



## **Product Features:**

- **Exterior:** 11.3-oz, 100% DWR polyester fleece with 4.8-oz, 100% DWR polyester taffeta at front panels
- Fill: 3.3-oz, poly-fill
- Raglan sleeves
- Ventilation eyelets under armpits
- Reflective REFERE on bottom left hem and storm flap - Reflective n on hood

Ladies' sizes: XS-4XL

## Icons/Fabric Features:



WARMTH RATING	MILD	• WARM	WARMER	WARMEST		
WATER PROTECTION	• w/	ATER RESISTANT	WAT	WATERPROOF		
WIND RESISTANT	YES					
WIND AND WATER PROTECTION	DWR					

Contoured fit

Zippered hand pockets with brushed tricot lining

— Spandex binding on cuffs and hem

## **Available Colours and PMS Colours**

Textile fabric colours are subject to dye lot variation and will not be exact match to print pantone reference



Due to the nature of polyester, special care must be taken throughout the decoration process.

### DF7680L - DryFrame® Dry Tech Insulated Water Resistant Fleece Ladies' Jacket

GARMENT MEASUREMENTS								
Size	XS	S	м	L	XL	2XL	3XL	4XL
Chest - Half Measure	18 1/2"	19 1/2"	20 1/2"	22"	23 1/2"	25"	27"	29"
Chest - Full Measure	37"	39"	41"	44"	47"	50"	54"	58"
Body Length from HPS (At Front)	24 1/2"	25"	25 1/2"	26 1/2"	27 1/2"	28 1/2"	29"	29 1/2"
Sleeve Length-CB	32 7/8"	33 3/8"	33 7/8"	34 3/8"	34 7/8"	35 3/8"	35 7/8"	36 3/8"
Einiskad manauramenta in inakan. Defer ta "Uaur ta Manaura" quida far debilad information an manaurament instructiona								

I measurements in inches. Refer to "How to Measure" guide for detailed information on measurement instructions.

LADIES' General Sizing Guide								
Size	XS	s	м	L	XL	2XL	3XL	4XL
Numeric Size	2	4-6	8-10	12-14	16	18-20	22	24
Bust	32"-34"	35"-36"	37"-38"	39"-41"	42"-44"	45"-47"	48"-51"	52"-55"
Waist	24"-25"	26"-27"	28"-30"	30"-32"	33"-35"	36"-38"	40"-42"	42"-44"
Нір	33"-35"	35"-37"	37"-39"	39"-41"	42"-44"	45"-47"	48"-50"	50"-52"
Sleeve Length-CB	30"-30 1/2"	30 1/2"-31"	31 1/2"-32"	32 1/2"-33"	33 1/2"-34"	34"-34 1/2"	34 1/2"-35"	34 1/2"-35"

# CONTROL YOUR CLIMATE®

### **DECORATING INSTRUCTIONS FOR POLYESTER FABRICS + INSULATED FABRICS**

#### Polyester Fleece instructions (arms, back and hood)

Due to the nature of polyester, special care must be taken throughout the decoration process. Here are some tips to effectively decorate our performance products.

• Garment temperature must not exceed 320°F or 160°C. Exceeding this temperature will cause the fabric to shrink, become wavy or cause dye migration.

• Dryer temperature and belt speeds must be changed accordingly for polyester fabric.

• If flashing these garments, do not exceed 1-2 seconds. Anything longer may damage the fabric as stated above.

Screen Printing: These garments require the use of poly inks that cures at a lower temperature. A Dyno Grey base blocker on all colours and a second white base blocker on all dark colours are recommended. Please consult your ink supplier for more information.

• Polyester requires a longer cooling time than cotton. Avoid overlap of garments and screen-print/heat transfer until the garments are cooled. Failure to cool the fabric prior to stacking into a printer's fold may cause the fabric and applied ink to stick together.

**Heat Transfers:** Poly mark heat transfers need to be created with an anti-migration layer in the design. This process can only be done on white or very light colour shirts. Inks used in printing paper design needs to be darker than the base fabric or colour will migrate with the fabric colour resulting in a bleeding effect.

**Sublimation Printing:** As noted for the poly mark heat transfers, this process can only be done on white or very light colour shirts. Inks used in printing paper design needs to be darker than the base fabric or colour will migrate with the fabric colour resulting in a bleeding effect.

• If you heat press these garments, you must adjust the time, temperature and pressure. Failure to do so may damage the fabric as stated above.

• A test sample run is recommended, especially if you have a large order or if your printer does not specialize in printing on performance fabrics.

#### Insulated instructions (front)

Due to poly-fill insulation, screen print or heat transfer treatment is not recommended